

Science and Technology Create Perfection

# Installation and Operating Manual

## **SR1028 SOLAR CONTROLLER**

For Split Pressurized Hot Water System



*Read the instruction carefully please before operation!*

## Contents

1. Safety information.....	3
1.1 Installation and commissioning .....	3
1.2 About this manual.....	3
1.3 Liability waiver.....	4
1.4 Important remark .....	4
1.5 Description of symbols .....	4
1.6 Description of operation button .....	5
2. Installation .....	5
2.1 Installing the controller.....	6
2.2 Terminal connection.....	6
3. Commissioning.....	8
3.1 Set time/week.....	8
3.2 Menu structure .....	9
3.3 Menu description .....	10
3.4 System description .....	11
4. Controller functions.....	12
4.1 Access main menu .....	12
4.2 Access submenu .....	12
4.3 Main menu DT O & DT F Temperature difference function .....	12
4.4 Main menu - THET timing heating.....	14
4.5 TEMP Temperature main menu .....	17
4.5.1 EM Emergency collector temperature (Emergency switch-off temperature of collector) .....	18
4.5.2 CMX Maximum limited collector temperature (collector cooling function) .....	19
4.5.3 CMN low temperature protection of collector.....	19
4.5.4 CFR frost protection of collector.....	20
4.5.5 SMX Maximum temperature of tank .....	21
4.5.6 REC Tank re-cooling function.....	21
4.5.7 C- F Celsius and Fahrenheit temperature transferring.....	22
4.6 HND Manual mode.....	22
4.7 PASS Password setting .....	23

4.8 LOAD Recovery factory setting.....	24
4.9 Manual heating .....	24
4.10 Holiday function .....	25
4.11 Temperature query function .....	26
5. Protection function.....	26
5.1. Memory protection .....	26
5.2 Screen protection .....	26
6. Trouble shooting .....	27
6.1 Trouble protection .....	27
6.2 Trouble checking .....	27
7. Quality Guarantee.....	29
8. Technical data .....	30
9. Delivery scope.....	31
10. Device matchable to this controller .....	31

## 1. Safety information

### 1.1 Installation and commissioning

- When laying cables, please ensure that no damage occurs to any of the constructional fire safety measures presented in the building.
- The controller must not be installed in rooms where easily inflammable gas mixtures are present or may occur.
- The permissible environmental conditions can't be exceeded at the site of installation.
- Before connecting the device, make sure that the energy supply matches the specifications that controller requires.
- All devices connected to the controller must conform to the technical specifications of the controller.
- All operations on an open regulator are only to be conducted cleared from the power supply. All safety regulations for working on the power supply are valid.
- Connecting and /or all operations that require opening the regulator (e.g. changing the fuse) are only to be conducted by specialists.

### 1.2 About this manual

This manual describes the installation, function and operation of a solar thermal controller.

When installing the remaining components e.g. the solar collectors, pump assemblies and the storage unit, are sure to observe the appropriate installation instructions provided by each manufacturer. Only trained professional personnel may only perform installation, electrical connection, commissioning and maintenance of the device. The professional personnel must be familiar with this manual and follow the instructions contained herein.

### 1.3 Liability waiver

The manufacturer cannot monitor the compliance with these instructions or the circumstances and methods used for installation, operation, utilization and maintenance of this controller. Improper installation can cause damages to material and persons. This is the reason why we do not take over responsibility and liability for losses, damages or cost that might arise due to improper installation, operation or wrong utilization and maintenance or that occurs in some connection with the aforementioned. Moreover we do not take over liability for patent infringements or infringements – occurring in connection with the use of this controller- on third parties rights. The manufacturer preserves the right to put changes to product, technical data or installation and operation instructions without prior notice. As soon as it becomes evident that safe operation is no longer possible (e.g. visible damage). Please immediate take the device out of operation. Note: ensure that the device cannot be accidentally placed into operation.

### 1.4 Important remark

We have carefully checked the text and pictures of this manual and provided the best of our knowledge and ideas, however inevitable errors maybe exist. Please note that we can not guarantee that this manual is given in the integrity of image and text, they are just some examples, and they apply only to our own system. Incorrect, incomplete and erroneous information and the resulting damage we do not take responsibility.

### 1.5 Description of symbols




Safety instruction:

The safety instructions in the manual are marked with a warning triangle. They indicate measures, which can lead to personal injury and safety risks.

Operation steps: small triangle “▶” is used to indicate operation step.

**Notes:** Contains important information about operation or function.

## 1.6 Description of operation button



No.	Button description
1	Display Screen
2	"Heating" manual heating button
3	"Holiday" button
4	"ESC" exit program setup
5	"-" Parameter adjust button
6	"+" Parameter adjust button
7	"SET" confirm button
8	"Clock" button

## 2. Installation




Controller can only be installed indoors, far away from dangerous place and away from the electromagnetic field. Controller should be equipped with an additional plug, which should have minimum 3mm distance between the pole of the plug or effective compliance with the provisions of the installation. For example, switch or fuse, please note that it should be separated between the wires, and use AC power.

## 2.1 Installing the controller

### Fixing the hang-panel of controller

The controller offer two kinds of smart installations:


- Optional A to fix the controller



- Optional B hang-panel of controller to fix Controller to wall, then use screw C to fix it.

## 2.2 Terminal connection

- Terminal layout



- Power connection

Input ports: Power cord input

- **Sensor input ports**

Input sensor ports T1: for Pt1000 sensor, used for measuring the temperature of collector.

Input sensor ports T2 and T3: for NTC10K, B=3950 sensors, used for measuring the temperature of tank.

- **Advice regarding the installation of temperature sensors:**

Only original factory equipped Pt1000 temperature sensors are approved for use with the collector, it is equipped with 1.5meter silicon cable and suitable for all weather conditions, the temperature sensor and cable are temperature resistant up to 280 °C, not necessary to distinguish the positive and negative polarity of the sensor connection.

Only original factory equipped NTC10K,B=3950 temperature sensors are approved for use with tank and pipe, it is equipped with 1.5meter PVC cable, and they are temperature resistant up to 105 °C, not necessary to distinguish the positive and negative polarity of the sensor connection.

All sensor cables carry low voltage, and to avoid inductive effects, must not be laid close to 230 volt or 400-volt cables (minimum separation of 100mm)

If external inductive effects are existed, e.g. from heavy current cables, overhead train cables, transformer substations, radio and television devices, amateur radio stations, microwave devices etc, then the cables to the sensors must be adequately shielded.

Sensor cables may be extended to a maximum length of ca. 100 meter, when cable's length is up to 50m, and then 0.75mm<sup>2</sup> cable should be used. When cable's length is up to 100m, and then 1.5mm<sup>2</sup> cable should be used.

- **Output ports**

**Output P1:** for hot water circuit pump, electromagnetic relay, and max. switching current 3.5A,

R1 ports are always open,

**Output H1:** for back-up electrical heater, electromagnetic relay, and max. switching current 10A, H1 connection ports are always open.



### 3. Commissioning

After switching on power to the controller, firstly it will ask for to set the time, password and parameters of system.

#### 3.1 Set time/week

▶ Press “Clock” button, time displays on screen, hour selection area “00” blinks on display screen.


▶ Press “+”“-” button to set hour of clock

▶ Press “Clock” button again, minute area “00” blinks


▶ Press “+”“-” button to set minute of clock.

▶ Press “ESC” button

to exit set program, or wait for 20 seconds to exit program automatically.



### 3.2 Menu structure



**Submenu:**

Through submenu, customer can set the parameter as desired value, please check it carefully.

### 3.3 Menu description

Code (Mainmenu)	Code (Submenu)	Code (Submenu)	Menu Description
DT O			Switch-on temperature difference
DT F			Switch-off temperature difference
THET			Timing heating
TEMP			Temperature
	EM		Limited temperature of collector (Emergency turnoff temperature of collector)
	CMX		Maximum temperature of collector (Collector cooling function)
	CMN		Low temperature protection of collector
	CFR		Frost protection of collector
	SMX		Maximum temperature of tank
	REC		Tank re-cooling function
	C-F		Celsius and Fahrenheit temperature transferring
HDN			Manual controlling
PASS			Password set
LOAD			Recovery to factory set

### 3.4 System description

**Note:**

T3 is alternative sensor, when no sensor (T3) is installed in the top part of tank, controller will use the signal of sensor T2 automatically to control the auxiliary heating or the circulation pump.


#### 1 collector array – 1 storage tank – 1 pump and auxiliary heating

**Description:**

The solar circuit pump (P1) is switched on as soon as the switch-on temperature difference ( $\Delta T_{on}$ ) between the collector array (T1) and the storage tank (T2) is reached. If the temperature difference between the collector array (T1) and storage tank (T2) drops below the switch-off temperature difference ( $\Delta T_{off}$ ), or the temperature of storage tank (T3) reaches the preset maximum storage temperature, then the solar circuit pump ( P1) is switched off.

#### Back-up heating by auxiliary boiler (detailed see paragraph 4.3):

Within the preset time section of back-up heating, if the temperature T3 is below the switch-on temperature, then the circulation pump ( H1) of back-up heating is triggered, when T3 is heated to the switch-off temperature, circulation pump H1 of back-up heating is ceased.



T1: Temperature sensor for collector array

T2: Temperature sensor in the top part of tank (optional sensor)

T3: Temperature sensor on hot water circulation pipe (optional sensor)

P1: Solar circuit pump

H1: output for back-up electrical heater

## 4. Controller functions

### 4.1 Access main menu

Under standby status, doing like following access main menu

- ▶ Press “SET” button, “PWD 0000” displays on screen, the left first digital blinks, ask for entering password, factory default set password is “0000”
- ▶ Press “+”“-” button to enter first digital of password.
- ▶ Press “SET” button again, the second digital blinks
- ▶ Press “+”“-” button button, to enter second digital of password
- ▶ Press “SET” button again, the third digital blinks
- ▶ Press “+”“-” button to enter the third digital of password
- ▶ Press “SET” button again, the fourth digital blinks
- ▶ Press “+”“-” button, to enter the fourth digital of password
- ▶ Press “SET” button again to access main menu
- ▶ Press “+”“-” button, can select the main menu
- ▶ Press “ESC” button to exit main menu



### 4.2 Access submenu

After selecting main menu, do like following access submenu

- ▶ Press “SET” button, to access submenu
- ▶ Press “+”“-” button to select submenu
- ▶ Press “SET” button again to access program, can adjust parameter value now
- ▶ Press “+”“-” button, to adjust the value of parameter
- ▶ Press “ESC” button, exit program of submenu
- ▶ Press “ESC” button again, to exit main menu.



Forexample: submenu

### 4.3 Main menu DT O & DT F Temperature difference function

**Description:**

Solar circuit pump R1 is triggered by the temperature difference function, so long as the temperature difference between collector and tank reaches the switch-on DT, solar circuit pump is triggered.

For example: the switch-on DT is 8°C, switch-off DT is 4°C, if the temperature in the bottom part of tank is 20°C, then just when collector temperature rises up to 28°C, pump is triggered, and when collector temperature drops to 24°C, pump is ceased.

Note: the switch-on/off DT of 8°C and 4°C are standard system setting according to many years' experience, only in special application cases it needs to be changed, (e.g far distance heat transferring), normally it is recommend to use default set. Switch-on and switch-off DT are alternating set. To avoid mistake the minimum difference between two temperature differences ( $\Delta T_{on} - \Delta T_{off}$ ) is set as 2°C.

**Setup the switch-on temperature difference:**

Under standby status, access main menu DT O,

▶ Press “SET” button, to access settings program of DT O, “DT O 08°C” displays on screen, “08°C” blinks, the switch-on temperature difference can be set.

▶ Press “+”“-” button, to adjust the value of switch-on DT, adjustable range (OFF+2°C)~20°C, factory setting is 8°C

▶ Press “ESC” button to exit this setting, parameter is saved automatically.



**Setup the switch-off temperature difference:**

Under standby status, access main menu DT F

▶ Press “SET” button, to access settings program of DT F, “DT F 04°C” displays on screen, “04°C” blinks, the switch-off temperature difference can be set.

▶ Press “+”“-” button to adjust the value of switch-off DT, adjustable range 0°C~(ON-2°C), factory set is 4°C.

▶ Press “ESC” to exit menu, or wait for 20 seconds to exit automatically, the setup parameters are saved automatically.



## 4.4 Main menu - THET timing heating

### Description:

Electrical heater, gas boiler or oil boiler can be integrated into solar system used as back-up of system, and they can be triggered automatically at preset time by preset temperature. Within a preset time section, when the temperature (T3) of top part of tank drops below the preset switching-on temperature of this function, back-up heating starts to work, when T3 rises up to the preset turning off temperature, back-up heating is stopped. Within 24 hours, three time sections can be set with this controller.

### Factory set:

The first time section: back-up heating function starts at 4:00 and ends at 5:00 am. Within this time section, switch-on temperature is 40°C, switch-off temperature is 45°C. The second time section: from 10:00 to 10:00 am, it means there is no back-up heating in this time.

The third time section: back-up heating function starts at 17:00 and ends at 22:00 pm. Within this time section, the switch-on temperature is 50°C, switch-off temperature is 55°C.

The switch-on temperature adjustable range: 10°C ~ (OFF-2 °C)

The switch-off temperature adjustable range: (ON+2 °C) ~ 80°C

If you want to shut off one timing heating, then you can set the turning on time and turning off time same value (for example, the second time section no this function, then you can set turning on/off time is 10:00 ~ 10:00)

When time is outside of the preset time section, back-up heating doesn't work automatically even when the tank temperature reaches the switch –on temperature of heating.

### Note:

- When there is no sensor installed in the top part of tank (no T3 sensor), controller will take the signal of T2 (sensor in bottom of tank) automatically to control this function.
- The time in this controlled is 24 hours, when you set time section, the switch-off time of heating should be larger than switch-on time. For example: if you set the switch-on time of heating is at 17:00, but switch-off time of heating is 6:00, then this setting doesn't take effect, that means within this time section, heating function doesn't work. The correct set is like flowing: it should be divided into two time sections, one time section is from 17:00 to 23:59, the other time section is from 00:00 to 06:00.

### Setup steps:

Under standby status, access main menu THET

► Press “SET” button, access THET program to set parameter, “tH 1o 04:00” displays

on screen, the switch-on time and temperature for first time section of heating function can be set

▶ Repress “SET” button, “04” of hour time blinks on screen

▶ Press “+”“-” button to adjust hour of time

▶ Repress “SET” button again, “00” of minute time blinks on screen

▶ Press “+”“-” button to adjust minute of time



▶ Repress “SET” button, temperature “40°C” blinks on screen

▶ Press “+”“-” button, to set the switch-on temperature of heating

▶ Then, Press “ESC” to exit this set and to access the switch-off time and temperature set

▶ Press “+” button, “tH 1F 05:00” displays on screen, the switch-off time and temperature for first time section of heating function can be set

▶ Press “SET” button, “05” of hour time blinks on screen.

▶ Press “+”“-” button to adjust hour of time

▶ Repress “SET” button, “00” of minute time blinks on screen

▶ Press “+”“-” button to set minute of time

▶ Repress “SET” button, temperature “45°C” blinks on screen

▶ Press “+”“-” button, to set switch-off temperature of heating

▶ Press “ESC” to exit this set program, parameters are saved automatically



---

▶ Press “+” button, “tH 2o 10:00” displays on screen, the switch-on time and temperature for the second time section of heating function can be set

▶ Press “SET” button, “10” of hour time blinks on screen

▶ Press “+”“-” button to adjust hour of time

▶ Repress “SET” button, “00” of minute time blinks on screen

▶ Press “+”“-” button to adjust minute of time

▶ Repress “SET” button, temperature “50°C” blinks on screen

▶ Press “+”“-” button to adjust switch-on temperature of heating





▶ Then press “ESC” to exit this set and to access the switch-off time and temperature set

▶ Press “+” button, “tH 2F 10:00” displays on screen, set the switch-off time and temperature of second time section of heating function



▶ Press “SET” button, “10” of hour time blinks on screen

▶ Press “+”“-” button to adjust hour of time

▶ Repress “SET” button, “00” of minute time blinks on screen

▶ Press “+”“-” button to adjust minute of time

▶ Repress “SET” button, temperature “55°C” blinks on screen


▶ Press “+”“-” button, to adjust switch-off temperature of heating

▶ Press “ESC” to exit this set program, parameter is saved automatically

---

▶ Press “+” button, “tH 3o 17:00” displays on screen, set the switch-on time and temperature of the third time section of heating function

▶ Press “SET” button, “17” of hour time blinks on screen



▶ Press “+”“-” button, to adjust hour of time

▶ Repress “SET” button, “00” of minute time blinks on screen

▶ Press “+”“-” button, to adjust minute of time

▶ Repress “SET” button, temperature “50°C” blinks on screen


▶ Press “+”“-” button, to adjust switch-on temperature of heating

▶ Press “ESC” to exit this set program and to the switch-off time and temperature set

▶ Press “+” button, “tH 3F 22:00” displays on screen, the switch-off time and

temperature of the third time section of heating function can be set

▶ Press “SET” button, “22” of hour time blinks on screen



▶ Press “+”“-” button, to adjust hour of time

▶ Repress “SET” button, “00” of minute time blinks on screen


▶ Press “+”“-” button to adjust minute of time

▶ Repress “SET” button, temperature “55°C” blinks on screen

▶ Press “+”“-” button to adjust switch-off temperature of heating

▶ Press “ESC” to exit menu, or wait for 20 seconds, set parameters are saved

automatically

**Note:** when no gas or oil boiler is installed in system, electrical heater can be installed as back-up device, when electrical heater is in operation status, signal  blinks on screen.

If customer use electrical heater as back-up, please according to the power of electrical heater to equip corresponding safety devices like contactor and breaker with this controller, we strongly recommend equipping with SR801 device with this controller, (SR801 detailed technical data see paragraph 10 spare parts)

## 4.5 TEMP Temperature main menu

For every system, the factory set parameters are in the best condition that is fully integrated into the entire solar system. But these parameters can also be set individually to cater the special requirements, please carefully observe the operation data of system components after setting.

Note: parameters that can be set depend on the selected system, not all the parameters can be adjusted in a solar system.  
Following submenu can be access though TEMP main menu.

### EM Emergency collector temperature

(Emergency switch-off temperature of collector) -----4.5.1

**CMX** Maximum limited collector temperature (collector cooling function) ----- 4.5.2

**CMN** low temperature protection of collector -----4.5.3

**CFR** frost protection of collector -----4.5.4

**SMX** Maximum temperature of tank-----4.5.5

**REC** Tank re-cooling function -----4.5.6

**C-F** Celsius and Fahrenheit temperature transferring-----4.5.7

Function	Adjustable range	Factory set	Function exit temperature
<b>EM</b> Emergency collector temperature Emergency switch-off temperature of collector)	120°C ~ 200°C	130°C	127°C
<b>CMX</b> Maximum limited collector temperature (collector cooling function)	110°C ~ 190°C	110°C	107°C

<b>CMN</b> low temperature protection of collector	0°C ~ 90°C	OFF	
<b>CFR</b> frost protection of collector	-10°C ~ 10°C	OFF	
<b>SMX</b> Maximum temperature of tank	2°C ~ 95°C	60°C	58°C
<b>REC</b> Tank re-cooling function		OFF	
<b>C-F</b> Celsius and Fahrenheit temperature transferring	°C ~ °F	°C	

#### 4.5.1 EM Emergency collector temperature (Emergency switch-off temperature of collector)

##### Function description:

When collector temperature rises up to the limited temperature (EM), this function is activated, solar circulation pump is stopped in order to avoid the damage of system other components caused by high temperature. The adjustable range of this EM temperature is (120°C ~ 200°C), factory set is 130°C. When the temperature of collector rises up to EM limited temperature, solar circuit pump is ceased, but when collector temperature drops to 127°C, solar circuit pump restarts, and this function is deactivated.

##### Setup steps:


to access main menu TEMP, then select submenu EM, "EM 130°C" displays on screen

▶ Press "SET" button, parameter "130°C" blinks.

▶ Press "+" "-" button, adjust EM temperature, adjustable range (120°C ~ 200°C), factory set is 130°C.

▶ Repreress "SET" button, activate and deactivate this function, if deactivate the function, "EM - - -" displays on screen.

▶ Press "ESC" button to exit menu or wait for 20 seconds to exit automatically, set parameters are saved automatically.



When this two signals of EM blinks on the screen, it indicates this function is in activated, and at this moment temperature of tanks reaches to its maximum limited temperature



When only this signal of EM blinks on the screen, it indicates this function is also activated, but temperature of tank doesn't reach to its maximum limited temperature

### 4.5.2 CMX Maximum limited collector temperature (collector cooling function)

#### Function description:

The collector cooling function delays the vaporization of the heat transfer fluid. Shortly before reaching the maximum temperature of the collector, the solar pump starts working in order to cool down the heat transfer fluid using the heat losses occurring in pipelines and storage cylinder.

When tank temperature rises to its preset maximal temperature, solar circuit pump is ceased compulsively even the temperature difference is satisfied. If the sunshine is very good, as a result collector temperature will rise continuously, when collector temperature rises up to its maximal temperature, solar pump will be triggered again even at the case that tank temperature is already to its maximal temperature. And solar pump works until the temperature of collector drops since this reversed circulation or when tank temperature rises its emergency temperature (95°C).

When ☀ displays, and Ⓛ blinks on the screen, it indicates that tank emergency temperature reaches, tank temperature is  $\geq 95^{\circ}\text{C}$

#### Setup steps:

To access main menu TEMP, then select submenu CMX “CMX 110°C” displays on screen

▶ Press “SET” button, parameter “110°C” blinks.

▶ Press “+”“-” button, to adjust the collector protection temperature, adjustable range (100°C~190°C) , factory set is 110°C

▶ Repress “SET” button, activate and deactivate this function, if deactivate the function, “CMX - - -” displays on screen.

▶ Press “ESC” button to exit the menu or wait for 20 seconds to exit automatically, parameters are saved automatically.



☀ CMX signal displays on screen, it indicates that this function is in activated.

### 4.5.3 CMN low temperature protection of collector

#### Description:

When the temperature of collector is below preset CMN temperatures, solar circuit pump is ceased, even when the temperature difference between collector and tank exceeds switch-on temperature difference, solar pump doesn't work yet. When temperature of collector is 3°C higher that the preset CMN temperature, solar circuit

pump is restarted, controller exits this program.

### Setup steps:

To access main menu TEMP, then select submenu CMN, "CMN-----" displays on screen, default set is off.

▶ Press "SET" button, default off signal "- -" blinks on screen.

▶ Repress "SET" button, to activate and deactivate this function

▶ Press "+" "-" button, to adjust the low protection



temperature of collector CMN, adjustable range (00°C ~90°C), after activate the function, factory set is 10°C

▶ Press "ESC" button to exit the menu or wait for 20 seconds to exit automatically, parameters are saved automatically.



CMN signal displays on screen, it indicates that this function is in activated.

## 4.5.4 CFR frost protection of collector

### Description:

In winter when the temperature of collector is below the preset frost protection temperature (factory set is 4°C), Solar circuit pump is triggered. Besides when tank temperature (T2) drops to 4°C, electrical heater is triggered automatically and it is in operation until T2 is heated up to 20°C or it is stopped when program of CFR is exited. When collector temperature rises up to 7°C, solar circuit pump is ceased, program of CFR exits automatically.

This function is used in system, which use water as heat transfer liquid, to avoid the freezing of solar heat transfer fluid.

### Setup steps:


To access main menu TEMP, then select submenu CFR, "CFR ----" displays on screen, default set is off.

▶ Press "SET" button, default off "- -" blinks.

▶ Repress "SET" button, to activate or deactivate this function

▶ Press "+" "-" button, to adjust the frost protection

function, adjustable range is (-10°C ~10°C), after



function activated, default set is 4°C

▶ Press “ESC” button to exit the menu or wait for 20 seconds to exit automatically, parameters are saved automatically.



CFR signal displays on screen, it indicates that this function is in activated.

**Note:** this function is only available in special solar system which using no-anti-freezing liquid; this kind of system is only suitable in area where the ambient temperature is near to 0°C in only few days. If safety requirement is very high , then anti-freezing is necessary, we suggest to use suitable anti-freezing liquid to avoid frost problem.

### 4.5.5 SMX Maximum temperature of tank

#### Description:

When the DT between collector T1 and Tank 2 caters the switch-on DT of circulation, solar pump is triggered, but in order to avoid the high temperature inside tank, controller will check whether the temperature (T3) of top part of tank is higher than maximum temperature of tank, when T3 is higher than preset SMX temperature, solar pump is ceased even at the case that DT caters condition. When tank temperature drops and is 2°C below the SMX, solar pump restarts when DT caters condition.

#### Setup steps:

To access main menu TEMP, then select submenu SMX, “SMX 60°C” displays on screen.

▶ Press “SET” button, parameter “60°C”blinks

▶ Press “+”“—” button to adjust the value of maximum temperature of tank1 adjustable range is

(2°C~95°C) , default set is 60°C

▶ Repress “SET” button to activate and deactivate this function, if function deactivated, “SMX - - -” displays on the screen.

▶ Press “ESC” button to exit the menu or wait for 20 seconds to exit automatically, parameters are saved automatically.



SMX signal displays on screen, it indicates that this function is in activated.



### 4.5.6 REC Tank re-cooling function

#### Description:

If tank temperature is over tank’s maximum temperature, and at the same time,

collector temperature is 5°C lower than tank temperature, then solar pump is triggered, through this reversed circulation, tank temperature is reduced by heat loss occurs in collector, solar pump keep in working until tank temperature drops below its maximum temperature.

**Setup steps:**

To access main menu TEMP, then select submenu REC, “REC OFF” displays on screen, default set is off.

▶ Press “SET” button, parameter “OFF” blinks on screen

▶ Repress “SET” button to activate or deactivate this function, after function activated; factory set is “REC ON”

▶ Press “ESC” button to exit the menu or wait for 20 seconds to exit automatically, parameters are saved automatically.



REC signal displays on screen, it indicates that this function is in activated.

### 4.5.7 C- F Celsius and Fahrenheit temperature transferring

**Setup steps:**

To access main menu TEMP, then select submenu C-F, “C\_\_F °C” displays on screen.

▶ Press “SET” button, parameter “°C” blinks on the screen.

▶ Press “+” button, to select between Celsius and Fahrenheit temperature, factory set is °C

▶ Press “ESC” button to exit menu or wait for 20 seconds to exit automatically, parameters are saved automatically.



### 4.6 HND Manual mode

When using this controller first time or when debugging this controller, output of this controller (R1,H1) can be triggered manually. “On, OFF” control.

**Setup steps:**

To access main menu HND,

- ▶ Press “SET” button, “HND1 off” displays on the screen, R1 output manually set
- ▶ Repress “SET” button, “HND1 on” displays on the screen, R1 output is switched-on
- ▶ Repress “SET” again, “HND1 off” displays, R1 output is switched-off
- ▶ Press “ESC” to exit R1 set program



- ▶ Press “+” button, “HND2 off” displays on the screen, H1 output manually set
- ▶ Press “SET” button, “HND2on” displays on the screen, H1 output is switched-on
- ▶ Repress “SET” again, “HND2off” displays, H1 output is switched-off
- ▶ Press “ESC” to exit H1 set program



**Note:** when manual mode is (H) activated, signal displays on the screen, after 15 minutes all outputs are switched-off, controller exits manual mode automatically.

## 4.7 PASS Password setting

### Setup steps:

To access main menu PASS,

- ▶ Press “SET” button, “PWDC 0000”, the left digital blinks, ask for to enter the password, factory set is “0000”
- ▶ Press “+”“-” button to enter the first digital
- ▶ Repress “SET” button, the second digital blinks
- ▶ Press “+”“-” button to enter the second digital
- ▶ Repress “SET” button, the third digital blinks
- ▶ Press “+”“-” button to enter the third digital
- ▶ Repress “SET” button, the fourth digital blinks
- ▶ Press “+”“-” button to enter the fourth digital
- ▶ Press “SET” button, “PWND 0000” displays on





the screen, ask for entering a new password, doing like above to enter the new password

▶ Press “SET” button, “PWDG 0000” displays on the screen, ask for reentering the new password, doing like above to reenter the new password, “PWOK” displays on the screen to indicate reentering password successfully.

▶ Press “ESC” button to exit set program or wait for 20 seconds to exit automatically.



**Warning!**

If the password is forgot, it is not possible to recover, but you can recover the password to factory set, then you can reedit a password like above descript steps, doing like following to recover to factory set.

▶ Open the connection terminal cover,

▶ Press “-” and hold down, then repress the reset button, which is on the terminal plate.

▶ Buzzer makes “du-----” 3 times, then release “-” button. Controller recovers to factory set, a new password can be reset now.

## 4.8 LOAD Recovery factory setting

**Setup steps:**

To access main menu REST,

▶ Press “SET” button, “YES” displays on the screen.

▶ Hold down “SET” button, buzzer makes “du-----” 3 times, then release “SET” button.



Controller recovers to factory set, new paramters can be reset now.

▶ Press “ESC” button to exit set program or wait for 20 seconds to exit automatically.

## 4.9 Manual heating



**Description:**

Electrical heater, gas or oil boiler can be as back-up devices in a solar system, this controller can achieve constant temperature controlling, when controller gets temperature signal of top part tank (T3) is 2°C below the preset temperature, back-up heating will be triggered. When temperature of top part tank (T3) reaches to the preset

temperature, heating is ceased.

Conditions for triggering manual heating function: the setting temperature should be 2°C higher than tank temperature.

**Activate/deactivate the function:**

- ▶ Press “Heating” button, temperature “60°C” blinks on the screen.
  - ▶ Press “+”“-” button to adjust switch-on temperature, adjustable range 10°C ~80°C, factory set is 60°C.
- After 20 seconds, this function is activated, signal  displays on the screen, and heating signal  blinks also.
- ▶ Press “Heating” button again, to switch-off manual heating function.

**Note:** manual heating can only heat tank one time, after manual heating is triggered, when temperature of tank rises up to the preset temperature, manual heating ceases, and manual heating function will be deactivated automatically, if customer wants to heat again, you need redo according to above steps.

## 4.10 Holiday function

**Description:**

This function activates in night, solar liquid will flow from storage tank to collector to cool the tank, and therefore to prevent high thermal loads problem of the solar system due to completely heated storage tank. The function is activated at night between 10 pm and 6 am, when the collector temperature drops 8 °C below the storage tank temperature (T2), solar circuit pump starts to work; when the temperature of collector is 2°C below the tank temperature, and solar circuit pump is ceased.

**Activate this function if:**

- You intend to be absent for an extended period (holiday)
- No hot water is required for an extended period.

**Note:** The function is deactivated when the temperature in lower section of storage tank falls down to 35°C.

### **Activate/ deactivate this function:**

- ▶ Press “Holiday” button for a long time until the signal of holiday function displays on the screen, and then holiday function is activated.
- ▶ Repress “Holiday” button, signal disappears, holiday function is deactivated.

#### **Note:**

This function is only activated when you are not at home for long time, when you come back; please make sure to deactivate it.

## **4.11 Temperature query function**

Under standby status,

- ▶ Press “+”“-” button can check the value of temperature sensors T1~ T3.

When checking temperature, T1 – T3 will displays one by one, corresponding sensor signal blinks.

- ▶ Press “ESC” button, clock and tank temperature can be displayed.

## **5. Protection function**

### **5.1. Memory protection**

In case power failure occurs, controller keeps the parameter settings unchanged.

### **5.2 Screen protection**


When no any press on button for 3 minutes, screen protection is activated automatically, and then LCD lighting lamp is switched-off. Through press any button to light LCD lamp again.



## 6. Trouble shooting

### 6.1 Trouble protection

When there is a break or short circuit between the connection of temperature sensors, controller switches off the corresponding functions and no more output signals are




given, at the same time error signals  are showed on the display. If control unit does not work correctly, please check following points.

► Press “+”“-” button to check error code,  signal displays on the LCD screen

Error message on LCD screen	Meaning	Cause of error	Error rectification
 T1 ---	T1 sensor problem	Sensor wiring interrupted, not connected or short circuit	Check resistance value, replace
 T2 ---	T2 sensor problem	Sensor wiring interrupted, not connected or short circuit	Check resistance value, replace

### 6.2 Trouble checking

The controller is quality product, conceived for years of continuous trouble-free operation. If a problem occurs, the cause of the problem very often lies not in the controller but in the peripheral components. The following description of some well-known problems should help the installer and operator to isolate the problem, so that the system can be place back into operation as quickly as possible and to avoid unnecessary costs. Of course, not all possible problems can be listed here. However, most of the normal problems encountered with the controller can be found in the list below, only return the controller to seller when you are absolutely sure that none of the problems listed below is responsible for the fault.

Symptoms	Secondary symptoms	Possible cause	Procedure
Controller does not appear to function at all	Display shows nothing, no display illumination	Controller power supply is interrupted or program is out of work	Check the controller power cable Press reset button
The solar pump doesn't operate, despite the fact that switch-on conditions are satisfied	The pump symbol in the display blinks	Pump power supply is interrupted	Check the pump power cable
Pump doesn't operate	The pump symbol in the display doesn't blink.   Lighted or  blinks	The maximum storage tank temperature (SMX) has been reached The maximum collector temperature (EM) has been reached.	No fault
	 T1-----  Error message displays on the screen	Fault (short circuit or open circuit) in a temperature sensor	On the controller, request the current values from all connected temperature sensors, replace all defective sensors and /or cabling.
The solar pumps operated, despite the fact that the switch-on conditions are not satisfied.	The pump symbol in the display blinks.	Frost protection function or tank re-cooling function is activated.	No problem, it is normal. If necessary to deactivate the corresponding functions.



**Warning!** Remove the device from the mains supply before opening the case. A potentially defective sensor can be checked using an ohmmeter. To do this, the sensor must be disconnected, its resistance measured, and the value compared with the figures in the table below, small deviation ( $\pm 1\%$ ) is acceptable.

**PT1000 resistance value**

°C	0	10	20	30	40	50	60	70	80	90	100
Ω	1000	1039	1077	1116	1155	1194	1232	1270	1309	1347	1385

**NTC 10K B=3950 resistance value**

°C	0	10	20	30	40	50	60	70	80	90	100
Ω	33620	20174	12535	8037	5301	3588	2486	1759	1270	933	697

## 7. Quality Guarantee

Manufacturer provides following quality responsibilities to end-users: within the period of quality responsibilities, manufacturer will exclude the failure caused by production and material selection. A correct installation will not lead to failure. When a user takes incorrect handling way, incorrect installation, improper or crud handling, wrong connection of sensor in system and incorrect operation, the quality responsibility is invalid for them.

The warrantee expires within 24 months after the date of purchasing the controller.

## 8. Technical data




Type Specification	Technical Data
Appearance of controller	205mm×150mm×60mm
Power supply	AC230V±10%
Power consumption	< 3W
Accuracy of temperature measuring	±2°C
Range of collector temperature measuring	-10~220°C
Range of tank temperature measuring	0~110°C
Inputs	1 x Pt1000 sensor (≤500°C) for collector (silicon cable≤280°C), 2 x NTC10K, B3950 sensor (≤ 135°C) for tank, (PVC cable ≤105°C),
Outputs	1 relays, for circulation pumps, power: ≤ 600W 1 relay for electrical heater, power: ≤ 1500W
Ambient temperature	-10~50 °C
Water proof grade	IP43

## 9. Delivery scope

Lists	Type	Quantity
Controller		1
Operation manual		1
PT1000 sensor (size: $\phi 6 \times 50\text{mm}$ , cable length 15m)		1
NTC10K (size: $\phi 6 \times 50\text{mm}$ , cable length 3m)		2
Plastic expansion screw		3
Screw		3

## 10. Device matchable to this controller

- Sensor for collector: high accuracy PT1000 sensor(A01)  
Parameter: PT1000,  $\phi 6 \times 50\text{mm}$
- Sensor for tank: high accuracy NTC 10K sensor (A02)  
Parameter: NTC10K, B=3950,  $\phi 6 \times 50\text{mm}$
- Thermowell of sensor: stainless thermowell (A05)  
Parameter: 1/2" male thread,  $\phi 8 \times 200\text{mm}$ .



- Contactor unit of high power: SR802

When user selects electrical heater as back-up device, we recommend using SR802 unit connecting controller and electrical heater.

Technical data of SR802

Dimension: 100mmx100mmx65mm

Power supply: 180V~264V/AC 50/60Hz

Suitable power:  $\leq 4000\text{W}$

Available ambient temperature:  $-10 \sim 50^{\circ}\text{C}$

Water proof grade: IP43

SR802 CONNECTION DIAGRAM:





